

MC-5005.1 WIRED KEYBOARD

EN

Introduction.

MODECOM MC-5005.1 Wired Keyboard is an exceptional item in the market . It was designed in such manner that dust, dirt and even accidental water spills could be easily removed from the keyboard without affecting it's operation. In addition it comes with additional Fn key which allows to gain access to 12 different shortcut functions such as multimedia control or access to most used system functions.

Specification.

- Dimensions: 442 x 148 x 24 mm
- Number of keys: 104
- Number of hot-keys 12
- Interface: USB
- USB cable length: 180 cm
- Weight: 506 g

Installation

System requirements.

Before proceeding with installation make sure your system fulfils below system requirements.

Windows Operating System

Available free USB port

Installation

Locate available USB port and connect the keyboard using its USB Plug to that port. Keyboard should be automatically detected and installed by the operating system. Keyboard is ready to be used

Shortcut functions

Fn + F1 = launch default multimedia player application

Fn + F2 = volume down

Fn + F3 = volume up

Fn + F4 = mute

Fn + F5 = previous track

Fn + F6 = next track

Fn + F7 = play/pause

Fn + F8 = stop

Fn + F9 = launch default web browser application

Fn + F10 = launch default mail client software

Fn + F11 = open „My computer“

Fn + F12 = open „Favorites“

Remark: All multimedia player hot-keys, were configured to work properly with the default Windows Media Player. However, many other programs can be operated with those keys as well. If your specific multimedia player doesn't react properly to pressing those keys, please consult it's help system to configure the application to make use of those hot-keys.



This device was designed and made of high-quality reusable materials and components.

If the device, its packaging, user's manual, etc. are marked with crossed waste container, it means they are subject to segregated household waste collection in compliance with the Directive 2012/19/EU of the European Parliament and of the Council. This marking informs that electric and electronic equipment shall not be thrown away together with household waste after it's been utilised. The user is obliged to bring the utilised equipment to electric and electronic waste collection point. Those running such collection points, including local collection points, shops or commune units, provide convenient system enabling to scrap such equipment. Appropriate waste management aids in avoiding consequences which are harmful for people and environment and result from dangerous materials used in the device, as well as improper storage and processing. Segregated household waste collection aids recycle materials and components of which the device was made. A household plays crucial role in contributing to recycling and reusing the waste equipment. This is the stage where the basics are shaped which largely influence the environment being our common good. Households are also one of the biggest users of small electrical equipment. Reasonable management at this stage aids and favours recycling. In the case of improper waste management, fixed penalties may be imposed in accordance with national legal regulations.