# MODECOM FREEWAY SX 7.0

Firmware updates >>> Windows CE 6.0

- **Charge navigation before updating**
- **Updating erases all data from the device**
- **Carry out update proces according to the instruction To run update proces a microSD card is required**

_____

1. Prepare a miicroSD memory card. The files will be loaded on it

2. Download from the link below compressed file and the extract all files to the microSD card

   http://freetab.eu/softy/ENG/Navigation/FreeWAY_SX_70/Firmware/Firmware_freeway_sx_70_2017a.zip

3. Place the microSD card in the navigation

4. Start the device and wait for the start of the screen calibration, calibrate the screen

INFO : NAND ID 2C 44 44 4B A9 00
READ BOOT CONFIG
CHECK SD CARD CONTENT
INFO : LOAD XIP.BIN
INFO : NO AK.BIN
SCAN NAND BLOCKS AND ERASE
PROGRESS <IIIIIIIIIIIIIIIIIIIIIIII>
INFO : BAD BLOCK NUMBER 16
PROGRAM METAZONE.BIN
PROGRAM METAZONE.BIN OK
FOUND LOGO.BMP
PROGRAM LOGO.BMP
PROGRAM LOGO.BMP OK
FOUND BAT.GIF
PROGRAM BAT.GIF
PROGRAM BAT.GIF OK
PROGRAM RTK.BIN
PROGRAM RTK.BIN OK
PROGRAM XIP.BIN

INFO : NAND ID 2C 44 44 4B A9 00
READ BOOT CONFIG
CHECK SD CARD CONTENT
INFO : LOAD XIP.BIN
INFO : NO AK.BIN
SCAN NAND BLOCKS AND ERASE
PROGRESS <IIIIIIIIIIIIIIIIIIIIIIII>
INFO : BAD BLOCK NUMBER 16
PROGRAM METAZONE.BIN
PROGRAM METAZONE.BIN OK
FOUND LOGO.BMP
PROGRAM LOGO.BMP
PROGRAM LOGO.BMP OK
FOUND BAT.GIF
PROGRAM BAT.GIF
PROGRAM BAT.GIF OK
PROGRAM RTK.BIN
PROGRAM RTK.BIN OK
PROGRAM XIP.BIN
PROGRAM XIP BACKUP
BACKUPXIP OK
CREATE NAK
SP WRITE IMAGE

App update

⬆️	back to up level	
📄	GPSAPP.MSK	✅

Calibrate

Update

Reboot

Exit

35%

PERFORM CALIBRATION

Özel kalemciği dikkatlice hedefin ortasına hafifçe basılı tutunuz
Ekrandaki diğer hedef noktalar içinde aynı işlemi yapın.

+

CLICK SCREEN TO UPDATE HAS BEEN RECORDED

Yeni kalibrasyon ayarlaması yapıldı
Ekrana dokunun ve yeni ayarı kayıt edin.

Time limit : 29 sec

AFTER STARTING PANEL NAVIGATION TURN OFF AND TURN ON VIA POWER BUTTON

10:11:21

Nawi...	Nawigacja	Muzyka	Video	Foto
Muzyka	E-teksty	Flash	Ulubione	Kalkulator
Desk	Transmiter FM	Język	Głośność	Podświetlenie