

■ MC-10B

**Bluetooth Headset
User' s Guide**

MODECOM

1. Introduction

The Bluetooth Headset allows you freely to make or receive calls whether on the journey or in the office. You can connect the headset with a compatible phone that supports Bluetooth wireless technology. Read this user guide carefully before using the headset. Read also the user guide for your phone, which provides important safety and maintenance information.

- Bluetooth wireless technology

Bluetooth wireless technology allows you to connect compatible communication devices without cables. A Bluetooth connection does not require that the phone and the headset should be in line of sight, but both devices should be within 10 meters(30 feet) between each other. Connections can be subject to interference from

obstructions, such as walls, or other electronic devices.

The headset is compliant with the Bluetooth Specification 2.0+EDR supporting the following profiles: Headset Profile 1.1 and Hands-Free Profile 1.5. Check with the manufacturers of other devices to determine their compatibility with this device.

2. Get started

- Overview

The headset contains the follo-

wing parts: Multifunction key

2. Microphone
3. Charger jack
4. Earphone
5. Earloop
6. Indicator light

Before using the headset, you must charge the battery and pair the headset with a compatible phone.

Note: Parts of the headset are magnetic, Metallic materials may be adhered to the headset. Do not place credit cards or other magnetic stora-

ge media near the headset because information stored in them may be erased.

- **Chargers and batteries**

Check if the charger is the affiliated device before using.

Warning: Use only batteries and chargers approved for use.

The use of any other types may invalidate any approval or warranty, and may be dangerous.

For availability of approved affiliated devices, please check with your dealer. When you di-

sconnect the power cord of any device, grasp and pull the plug, instead of the cord.

- **Charge the battery**

This device has an internal, nonremovable, rechargeable battery. Do not attempt to remove the battery from the device as you may damage the device.

1. Connect the charger cable to the headset.
2. Connect the charger to an electrical outlet. The red indicator light is on during charging.

3. If charging does not start, disconnect the charger, plug it in again, and retry. Charging the battery fully may take up to 2 hours.

4. When the battery is fully charged, the red indicator light turns off and the blue indicator light turns on. Disconnect the charger from the electrical outlet and the headset. The fully charged battery has power for up to 3 hours-6 hours 30 minutes of talk-time or up to 100 ho-

urs-180 hours of standby time. However, the talk and standby time may vary with different mobile phones, products that use a Bluetooth connection, usage settings, styles, and environments.

- Switch the headset on or off
To switch on, press and hold the multifunction key, The headset beeps, and the blue indicator light is displayed. When the headset is connected to a paired phone and is ready for use,

the blue indicator light flashes slowly. To switch off, press and hold the multifunction key. The headset beeps, and the blue indicator light is flashing twice.

- Pair the headset with a compatible phone

1. Press and hold multi-Functional button until the indicator light turns on in blue

2. Activate the Bluetooth feature on the phone, and set the phone to search for Bluetooth devices.

3. Select the headset from the list of found devices.

4. Enter the passcode 0000 to pair and connect the headset to your phone. If the pairing is successful, the indicator light will flash in blue 2 times, In some phones you may need to make the connection separately after pairing. See the user guide of your phone for details. You only need to pair the headset with your phone once.

5. If the pairing is successful,

the headset beeps and appears in the phone menu where you can view the currently paired Bluetooth devices.

Disconnect the headset from the phone

To disconnect the headset from your phone (for example, to connect the phone to another Bluetooth device), you can find how to make it in the following ways:

- Switch off the headset.
- Disconnect the headset in the

Bluetooth menu of your phone.

- Move the headset 10 meters (30 feet) away from the phone. You do not need to delete the Bluetooth headset from your phone's Bluetooth device list if you want to disconnect the headset with your phone. Reconnect the paired headset with your phone. To reconnect the headset with your phone, please switch on the headset and it will be connected with your phone automatically, this is subject to the phone.

- **Troubleshooting**

If you cannot connect the headset with your phone, do as followings: Ensure that the headset is charged, switched on, and paired with and connected to your phone.

Ensure that the Bluetooth function is activated on your phone. Check that the headset is within 10 meters(30 feet)from your phone and that there are no obstacles between the headset and the phone, such as walls or

other electronic devices.

3. Basic use

- **Call administration**

To make a call, use your phone in the normal way when the headset is connected with your phone. The blue indicator light flashes slowly during the call

If your phone supports redialing with this device, press the multifunction key for 2 sec. when no call is in progress.

If your phone supports voice dialing with this device, press and

hold the multifunction key when no call is in progress, and proceed as described in the user guide of your phone.

When you receive a call, the blue indicator light flashes quickly, and you hear a ringing tone through the headset. To answer the call, press the multifunction key, or use the phone keys. If the automatic answer function is on, the phone automatically answers the incoming call after one ring. To reject an incoming call, brie-

fly press the multifunction key twice. Or use the phone keys.

To end a call, press the multifunction key. or use the phone keys.

- Switch the call between phone and headset. To switch the call between the headset and a compatible phone, press and hold the multifunction key for 2 seconds, or use the respective function in your phone.

- Use the headset with several phones

You can pair the headset with up to eight phones but connect it with only one phone at a time.

The phone that was first paired with the headset is the default phone. If the headset is switched on within 10 meters(30 feet) of several paired phones, the headset tries to connect with the default phone. If the headset cannot connect with the default phone, the headset tries to connect with the last used phone, if the headset cannot connect with this phone

either, one of the other six paired phones can be connected with the headset.

To make the connection, see the user guide of your phone.

4. Battery information

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear

out. Recharge your battery only with approved chargers designated for this device. Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time. Never use any charger that is damaged.

Leaving the device in hot or cold places, such as in closed

car in summer or winter conditions, will reduce the capacity and life time of the battery.

Always try to keep the battery between 15C and 25C (59 F and 77F). A device with a hot or cold battery may not work temporarily, even if the battery is fully charged. Battery performance is particularly limited in temperatures below freezing.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if dama-

ged. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Maintenance

Your device is a product with superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

Keep all accessories and enhancements out of reach of small children.

Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, allow it to dry completely.

Instrukcja obsługi słuchawki MC-10B

1. Wprowadzenie.

Dziękujemy za zakup produktu MODECOM. Mam nadzieję, że dzięki bezprzewodowej słuchawce bluetooth MC-10B, użytkowanie telefonu komórkowego, laptopa a nawet odtwarzacza będzie znacznie łatwiejsze, wygodniejsze a przede wszystkim bezpieczniejsze. Uprzejmie prosimy o zapo-

znanie się z niniejszą instrukcją obsługi.

• Technologia Bluetooth

Bezprzewodowa technologia bluetooth pozwala na podłączenie słuchawki bez użycia kabla do kompatybilnych z nią urządzeniami. Transmisja odbywa się na zasadzie fal o zasięgu zwykle do 10 metrów. Połączenie może być zakłócone przez takie przeszkody jak : ściany, fale pochodzące z urządzeń elektronicznych itp.

Zestaw słuchawkowy jest zgodny ze specyfikacją Bluetooth 2.0 + EDR można również korzystać z następujących profili: Headset Profile 1.1 i Hands-Free

Profil 1.5. Należy sprawdzić z urządzeniem w celu określenia ich zgodności z produktem.

2. Informacje ogólne

- Zestaw słuchawkowy MC-10B zawiera :
 - Słuchawkę MC-10B
 - Zaczep do ucha

-ładowarkę

-instrukcję obsługi

Przed użyciem słuchawki należy ją naładować i połączyć z kompatybilnym telefonem.

UWAGA: Zestaw zawiera części magnetyczne. Należy uniknąć kontaktu produktu z innymi magnetycznymi urządzeniami w tym z kartami płatniczymi ,gdyż mogą one ulec uszkodzeniu.

• Ładowanie baterii

W celu poprawnego ładowania używaj zawsze oryginalnej ła-

dowarki. Zastosowanie nieoryginalnego sprzętu grozi utratą gwarancji a także uszkodzeniem urządzenia.

Po zakończeniu ładowania zawsze wyjmuj ładowarkę z kontaktu za obudowę–nigdy za kabel.

Bateria zastosowana w słuchawce MC-10B jest wewnętrzną, niewymienialną częścią sprzętu–nie należy podejmować prób wymiany baterii gdyż grozi to utratą gwarancji.

Poprawne ładowanie zestawu

słuchawkowego:

- a) Podłącz ładowarkę do słuchawki
- b) Włóż wtyczkę ładowarki do źródła prądu
- c) Ładowanie słuchawki sygnalizuje czerwona dioda
- d) Zakończenie ładowania sygnalizuje zmiana koloru diody z czerwonej na niebieską
- e) Czas ładowania wynosi ok. 3 godzin
- f) Po zakończeniu ładowania odłącz ładowarkę od źródła prądu

du a następnie od słuchawki.

Naładowana bateria wystarcza na maksymalnie 3 - 6 godzin rozmów lub od 100 do 180 godzin czasu czuwania.

Czas rozmów i czuwania mogą się różnić w zależności od używanego modelu telefonu komórkowego, ustawień, intensywności użytkowania i środowiska pracy.

- Włączanie oraz wyłączanie zestawu słuchawkowego

W celu włączenia urządzenia,

naciśnij i przytrzymaj klawisz wielofunkcyjny znajdujący się na słuchawce. Urządzenie wyemituje krótkie sygnały dźwiękowe a także zapali się niebieskie światło wskaźnika. Gdy zestaw słuchawkowy jest połączony z powiązaniem telefonem i jest gotowy do użycia, niebieskie światło wskaźnika migie z wolną częstotliwością. Aby wyłączyć zestaw słuchawkowy należy nacisnąć i przytrzymać klawisz wielofunkcyjny.

Nastąpi seria krótkich sygnałów dźwiękowych , niebieska dioda wskaźnika mignie dwa razy po czym zgaśnie.

8 Nawiązywanie połączenia z kompaktbilnym urządzeniem.

a) Naciśnij i przytrzymaj przycisk funkcjonalny znajdujący się na słuchawce

b) Aktywuj w swoim urządzeniu funkcję bluetooth

c) Wybierz słuchawkę MC-10B z listy znalezionych urządzeń

d) Wprowadź hasło „0000”aby

nawiązać połączenie

e) Nawiązanie połączenia będzie sygnalizowała pulsująca niebieska dioda na słuchawce.

- Odłączanie słuchawki od powiązanego urządzenia

W celu odłączenia zestawu słuchawkowego należy wykonać jedną z poniższych czynności:

- oddalić zestaw słuchawkowy na odległość większa niż 10 metrów od telefon

- wyłączyć zestaw słuchawkowy poprzez przytrzymanie

przycisku wielofunkcyjnego
-odłączyć zestaw słuchawkowy poprzez menu telefonu lub innego komaktybilnego urządzenia

- Rozwiązywanie problemów

Jeśli nie jest możliwe połączenie zestawu słuchawkowego z kompaktybilnymi urządzeniami postępując zgodnie z instrukcją upewnij się że:

- słuchawka jest naładowana
- telefon ma włączoną funkcję bluetooth

- odległość pomiędzy urządzeniem a słuchawką jest mniejsza niż 10 metrów i nie występują żadne przeszkody w postaci ściany, urządzeń elektronicznych imitujących fale itp.

3. Nawiązywanie połączenia za pomocą słuchawki MC-10B.

W celu nawiązania połączenia należy wybrać żądany numer telefonu z listy kontaktów i nacisnąć odpowiedni przysk połączenia dedykowany do konkretnego modelu telefonu.

Jeżeli aparat wyposażony jest w funkcję wybierania głosowego numeru telefonu należy przytrzymać na słuchawce przycisk wielofunkcyjny i wypowiedzieć nazwę żądanego kontaktu.

ENVIRONMENT PROTECTION:



This symbol on our product nameplates proves its compatibility with the EU Directive 2002/96 concerning proper disposal of waste electric and electronic equipment (WEEE). By using the appropriate disposal systems you prevent the potential negative consequences of wrong

product takeback that can pose risks to the environment and human health. The symbol indicates that this product must not be disposed of with your other waste. You must hand it over to a designated collection point for the recycling of electrical and electronic equipment waste. The disposal of the product should obey all the specific Community waste

management legislations. Contact your local city office, your waste disposal service or the place of purchase for more information on the collection. Weight of the device: 10 g

OCHRONA ŚRODOWISKA:



Niniejsze urządzenie oznakowane jest zgodnie z dyrektywą Unii Europejskiej 2002/96/UE dotyczącą utylizacji urządzeń elektrycznych i elektronicznych (WEEE). Zapewniając prawidłowe usuwanie tego produktu, zapobiegasz potencjalnym negatywnym konsekwencjom dla środowiska naturalnego i zdrowia

ludzkiego, które mogą zostać zagrożone z powodu niewłaściwego sposobu usuwania tego produktu. Symbol umieszczony na produkcie wskazuje, że nie można traktować go na równi z innymi odpadami z gospodarstwa domowego. Należy oddać go do punktu zbiórki zajmującego się recyklingiem urządzeń elektrycznych i elektronicznych. Usuwanie

urządzenia musi odbywać się zgodnie z lokalnie obowiązującymi przepisami ochrony środowiska dotyczącymi usuwania odpadów. Szczegółowe informacje dotyczące usuwania, odzysku i recyklingu niniejszego produktu można uzyskać w urzędzie miejskim, zakładzie oczyszczania lub sklepie, w którym nabyłeś niniejszy produkt. Masa sprzętu: 10 g

